



# Window Adjustment

## Window Hinges

Windows are fitted with adjustable friction hinges. The hinge may loosen with time and can be tightened by adjusting the small screw on the base of the hinge.

## Window Handles

Window handles are secured by two screws. One of the screws will be visible when the handle is in the open position. The other screw is concealed under a small cover which can easily be removed with a knife blade (see Fig 1). Periodically check the screws for tightness, taking care not to over-tighten.

